


Parts List Lever Hoist



No	Description	250kg	500kg
1	Top Hook Assembly (Incl. #2)	1	1
2	Safety latch Kit	2	2
3	Top Hook Shaft	1	1
4	Bottom Hook Assembly (Incl. #2)	1	1
5	Chain Pin & Locking Nut	1	1
7	Gear Case	1	1
8	Reinforced Plate	1	1
9	Load Gear	2	2
10	Driving Pinion	1	1
11	Right Side Plate	1	1
12	Chain Stripper	1	1
13	Stay Bolt	2	2
14	Pin	NA	1
16	Load Gear	1	1
17	Load Sheave	1	1
18	Chain Guide	2	2
19	Left Side Plate Assembly	1	1
20	Pawl Spring	2	2
21	Pawl Spring	2	2
22	Snap Ring for Pawl	2	2
23	Break Seat	1	1
24	Ratchet Disc	1	1
25	Friction Disc	2	2
26	Spring	1	1
27	Brake Plate	1	1
28	Bushing	1	1
29	Stop Knob	1	1
30	Brake Cover	1	1
31	Socket Head Screw & Spring Washer	3	3
33	Snap Ring for Brake Seat	1	NA
34	Change Over Gear	1	1
35	Lever Handle Assembly	1	1
	Lever Handle	1	1
	Selector Lever	1	1
	Change Over Pawl	1	1
	Snap Ring for Change Over Pawl	1	1
	Roller	1	1
	Change Over Spring	1	1
36	Snap Ring	1	1
37	Hand Wheel	1	1
38	Snap Ring for Hand Wheel	1	1
40	Handle Sleeve	1	1
41	Bolt & Nut	1	1
48	Load Chain	1	1
49	End Ring	1	1